

U.S. Update

● New Program with Easier Game Play for Asteroids Deluxe™

The read-only memories (ROMs) in this kit contain a new program that changes the Asteroids Deluxe™ game play. To attract new players, the game play is now operator-adjustable to be either easy for approximately the first 30,000 points or hard throughout the game.

The technical manual describes the game play correctly if the game PCB option switch at R5 is set to "hard." If you set the switch to "easy", then the following game-play changes happen:

- **Four** large asteroids begin the game. The second wave of asteroids begins with **five**, and the subsequent waves start with six through nine large asteroids. In addition, the asteroids move

much more slowly across the screen. (If the option switch is set to hard, the waves begin with six to nine large asteroids.)

- The large ships ("death stars") when shot will break up into three **slowly-moving** diamonds. (If the option switch is set to hard, diamonds would immediately begin chasing the player's spaceship at high speed.)

After installing these five ROMs, we recommend you set your game to **easy game play**. To do so, refer to the figure that follows. You should note also that the self-test now displays an additional 0 or 1 to represent your game difficulty selection.

Game Option Settings

To change toggle positions on the switch assemblies, you need not remove the game PCB. The switches, usually colored blue, are easily accessible when the Asteroids Deluxe™ Game PCB is mounted in place.


When changing the options, verify proper results on the monitor display by performing the **self-test**. Note that changing an option on any of the following eight toggles will cause an immediate change on the monitor screen during the self-test.

Toggle Settings of 8-Toggle Switch on Asteroids Deluxe PCB (at R5—LEFT switch when PCB is in game)								
8	7	6	5	4	3	2	1	Option
						On	On	English language \$
						On	Off	German language
						Off	On	French language
						Off	Off	Spanish language
						On	On	Game starts with 2 ships
						On	Off	Game starts with 3 ships \$
						Off	On	Game starts with 4 ships
						Off	Off	Game starts with 5 ships
								1-play minimum \$
								2-play minimum
								Easier game play for first 30,000 points \$
								Hard game play throughout game
								Bonus ship at every 10,000 points \$
								Bonus ship at every 12,000 points
								Bonus ship at every 15,000 points
								No bonus ship
On	On							
On	Off							
Off	On							
Off	Off							


\$ Manufacturer's suggested settings

Continued on reverse side

Self-Test Procedure, continued



To install the five new ROMs in this kit, refer to the drawing and parts list that follow:



Asteroids Deluxe™ Game PCB Assembly A036471-03 and -04 F

Part No.	Description (Reference Designations and Locations in Bold)
036430-02	Read-Only Memory (D1)
036431-02	Read-Only Memory (E/F1)
036432-02	Read-Only Memory (H1)
036433-03	Read-Only Memory (J1)
036800-02	Read-Only Memory (R2)

